

SPEAKMAN COMPANY
SENTINEL MARK II SHOWERPAC
VERTICAL PIPE COVER

INSTALLATION INSTRUCTIONS

Note: VPC-2 cover is 24 inches long.

- 1) After the complete Showerpac unit, less top cover plate, has been installed, measure from the top of shield to the finished ceiling. If measurement is over 25 inches, two (2) VPC-2 covers will have to be used.
- 2) If the cover must be cut, make sure the cut is made on the end with **no** holes. Cut cover to the proper length determined in Step 1 (if needed). Remove protective film from cover.
- 3) Remove the valve handle and the shield assembly (total of four (4) screws) from the Showerpac unit. Attach union bracket to the shield assembly using the three (3) 3/8 long screws provided for the Showerpac top cover plate. Do not tighten screws. Attach cover to the union bracket of the shield assembly with screws provided. Do not tighten screws.
- 4) Attach shield/cover assembly to the unit using the three (3) screws and tighten. Attach the handle to the valve with screw and tighten. If only using one VPC-2 cover, proceed to Step #6.
- 5) **Two (2) VPC-2 Covers Only**
Measure to see if the second cover needs to be cut. If the cover must be cut, make sure the cut is made on the end **with** holes. Remove protective film from cover. Position second cover (cut side up against the ceil) on top of first cover and hold in place. Place top cover bracket over covers, so that it is centered within the two (2) covers. Mark the location of bracket mounting holes (2). Remove bracket and install mounting anchors (if needed) (not provided). Secure bracket to wall with mounting screws (not provided).
- 6) Place top cover bracket over cover and against finished ceiling. Mark the location of bracket mounting holes (2). Remove bracket and install mounting anchors (if needed) (not provided). Secure bracket to wall with mounting screws (not provided).
- 7) Tighten six (6) union bracket screws.